

## Installation Instruction for WAPC 802.11/GSM Rubber Case

### 1. Installation

- Figure A: Insert WAPC handheld through opening of rubber boot and securely fit the front end of the WAPC handheld in the end of the rubber boot.
- Figure B & C: Firmly pull bottom corners of rubber boot (one at a time works best) around the end of the WAPC handheld until securely enclosed.
- Figure D: Complete.



**Figure A**



**Figure B**



**Figure C**



**Figure D**

**COMPANY HEADQUARTERS AND CANADIAN SERVICE CENTRE**

PSION Inc.

2100 Meadowvale Boulevard, Mississauga

Ontario, Canada L5N 7J9

Tel: +1 905 813 9900

Fax: +1 905 812 6300

E-mail: [salescdn@psion.com](mailto:salescdn@psion.com)

[www.pSION.com](http://www.pSION.com)

[www.ingenuityworking.com](http://www.ingenuityworking.com)